

LINILUX SURFACE (SF)


Installation Manual

1





Attention

Switch off power at the mains.




2

Remove the LINILUX BASE from LINILUX luminaire




3




LINILUX SURFACE (SF)

Installation Manual

3



4



5

