


ORIGIN RC RT 07 (7.2W)


Installation Manual

1




Attention

Before any maintenance switch off the main power.




2



Cut-out 163x32mm

3





4




Attention!

Make sure that all connections are properly executed in order to maintain the wiring ip grade.



5



6

