ORIGIN RC RT 13 (13W) Installation Manual 2 3 131 Before any maintenance switch off the main power. 129 Cut-out 280x131mm 5 6 Make sure that the body of the luminaire is closed properly with the base before tightening the screws 230VAC

