


ORIGIN RC SQ 04 (4W)

Installation Manual




Attention

Before any maintenance switch off the main power.




1




Cut-out 109x117mm


2



3




4




5

Make sure that the body of the luminaire is closed properly with the base before tightening the screws



6



7

