




# REFORM 30 IN-OUT RECESSED


## Installation Manual




### To pull OUT the spot



1. Push in the spot.





2. Turn the spot left to unlock.




3. Once the spot is unlocked pull it downwards to the desired level.


### To pull IN the spot



1. Push the spot inside.



2. Once all the spot is inside then turn the spot right.



3. Release the spot to lock.

# REFORM 30 IN-OUT RECESSED

Installation Manual




1




### Attention

Before any maintenance switch off the main power.




2

2.1




2.2

Connect the LED Driver at 230VAC.




3


3.1



3.2



3.3



4

